TABLE TOPS mecalit®-PRO

Material & Care



MATERIAL









- SIEGER uses only PEFC-certified raw chipboard for mecalit® table tops.
- PEFC stands for "Program for the Endorsement of Forest Certification", i.e. the initiative for the support of certified forests. The aim of this label is to improve forest management with regard to social, ecological and economic standards. The PEFC label guarantees that wood and paper products come from sustainably managed forests. This is monitored by independent organizations.
- Table tops "Made in Germany".
- Tops: high-density decorative particle boards with melamine coating on both sides.
- Top edge: polypropylene
- In a thermoplastic injection moulding process the decorative chipboards receive a beautifully shaped, hermetically sealed, colour-matching and highly impact-resistant edge, which rounds off the appearance of the tables with its elegant textured surface.

PROPERTIES

- Table tops ideally suited for outdoor use.
- Dimensionally stable and load-bearing compact table top.
- Hermetically sealed against moisture, highly impact-resistant table top edge.
- Weather resistant in accordance with DIN EN ISO 4892-2.
- Increased UV resistance and scratch resistance.
- Colour fastness of the surface tested for 3 years in Central Europe.
- Self-supporting and rigid.
- Cold and acid resistant.
- The high-quality surface can withstand higher temperatures such as cigarette burns or hot cooking pots for short periods.
- Hard-wearing and easy to clean.

CARE

We recommend:

- Remove any dirt from the surface immediately to avoid staining or damage to the surface.
- Remove light soiling with a soft cloth or sponge, a soft brush, lukewarm water and a pH-neutral cleaning agent or mild soapy water.
- Simply rinse off any cleaning residue with clear water and rub dry with a cloth.
- Soften stubborn or dried-on dirt with a light, lukewarm soapy solution and wipe off carefully.
- Wipe off oils or sun cream immediately, as they are burnt in by the sun and can lead to staining.

TABLE TOPS mecalit®-PRO

Material & Care



To avoid staining, do not clean the furniture in direct sunlight. The surface temperature should not exceed 25°C during cleaning.

Never use for cleaning:

- Cleaners containing chlorine, acids or solvents.
- Scratching or abrasive agents.
- Hard brushes or steel wool.
- Products with aggressive chemical additives.
- Strongly acidic or alkaline solvents.
- High-pressure cleaners.

These can damage the surface.

Notes:

- Do not leave decorations such as vases and the like on the table top for a longer period of time as colour differences or edges could form in these areas. Glass containers with liquids can develop a burning glass effect when exposed to direct sunlight.
- Make sure that no rainwater collects on the table top over a longer period. If possible, wipe dry or, depending on the model, fold down the table or place it at a slight angle so that the water can run off.

STORAGE

• Even though SIEGER furniture is resistant to the effects of the weather, winter storage indoors or in dry, sheltered areas keeps the furniture looking good for longer and at the same time protects it from soiling.

We recommend:

- Store in a dry place.
- Store frost-free, but not overheated.
- Protect from UV radiation during the winter.
- Avoid large temperature fluctuations.
- Ensure good ventilation.
- If winter storage indoors or in a dry, sheltered place is not possible, we recommend protecting the furniture with commercially available covers. To allow air to circulate and prevent waterlogging or condensation, these should not rest on the ground or on the product. Plastic wedges or similar spacers are suitable for this purpose. Alternatively, remove the protective covers regularly for short periods. Water should be able to run off easily and not remain on the protective cover. Always remove snow from the cover. Failure to do so can lead to mould or mildew stains on the furniture.

NOTES

- Decorative defects are permissible in accordance with DIN EN 438-6, relate to a maximum surface area of 2.0 mm²/m² and are unlimited in number.
- Conditions of use in accordance with DIN EN 581-3: Outdoor furniture Tables with mecalit-PRO® tops are suitable for use in residential or commercial areas.
- Slight distortion of the table top is inherent to the material and is therefore permissible and not to be classified as a product defect or reason for complaint.
- To protect the frames, the furniture is fitted with plastic foot caps or floor glides. Like all plastics, these are subject to abrasion, which can vary depending on the structure and colour of the floor and may leave streaks. This does not constitute a product defect.