

ROPE WEAVE

Material & Care



MATERIAL

- Rope: Ropes or ribbons that are braided from high-strength and through-dyed polyester yarn.

PROPERTIES

- Robust and hardwearing.
- Tear-resistant and dimensionally stable.
- Breathable, dirt-repellent and easy-care.
- Good air circulation and pleasant to the touch.
- The polyester ropes absorb hardly any moisture and are therefore quick-drying.
- High UV stability. Colour fastness of the surface tested for 3 years in Central Europe.

CARE

We recommend:

- Clean the rope weave regularly with lukewarm water, a cloth or a soft sponge to prevent dirt from sticking to it.
- Before cleaning with water, be sure to brush off loose dirt and dust particles with a soft brush.
- Always remove stains and dirt immediately to prevent them from penetrating too deeply into the rope weave. Remove them with mild soapy water, a cloth, a sponge or a soft brush. Always rinse well with clean water and allow to air dry completely in the shade.

Never use for cleaning:

- Cleaners containing chlorine, acids or solvents.
- Scratching or abrasive agents.
- Hard brushes or steel wool.
- Products with aggressive chemical additives.
- Strongly acidic or alkaline solvents.
- High-pressure cleaners.

These can damage the surface.

STORAGE

- Even though SIEGER furniture is resistant to the effects of the weather, winter storage indoors or in dry, sheltered areas keeps the furniture looking good for longer and at the same time protects it from soiling.

We recommend:

- Store in a dry place.
- Store frost-free, but not overheated.
- Protect from UV radiation during the winter.
- Avoid large temperature fluctuations.
- Ensure good ventilation.

ROPE WEAVE

Material & Care



-
- If winter storage indoors or in a dry, sheltered place is not possible, we recommend protecting the furniture with commercially available covers. To allow air to circulate and prevent waterlogging or condensation, these should not rest on the ground or on the product. Plastic wedges or similar spacers are suitable for this purpose. Alternatively, remove the protective covers regularly for short periods. Water should be able to run off easily and not remain on the protective cover. Always remove snow from the cover. Failure to do so can lead to mould or mildew stains on the furniture.

NOTE

- Be careful when handling sharp objects. They could damage the rope weave.
- Direct exposure to fire and hot objects can cause permanent damage to the weave.